

OPTIONAL PARTS FOR OUTDOOR UNITS

>>For PUMY series

Description	Model
Branch Pipe (2 Branch)	CMY-Y62-G-E
Header	CMY-Y64-G-E
Header	CMY-Y68-G-E
Drain Socket	PAC-SG61DS-E
Centralized Drain Pan	PAC-SH97DP-E
Port Connector (ø9.52 → ø12.7)	PAC-SG73RJ-E
Port Connector (ø15.88 → ø19.05)	PAC-SG75RJ-E
Air Protect Guide (2 pcs required)	PAC-SH95AG-E
Air Outlet Guide	PAC-SH96SG-E
Base Heater	PAC-SJ20BH-E

>>For PUHY series

Description	Model	Remarks
Twinning kit	CMY-Y100VBK2 / 3	For PUHY-P500-P650 / EP400-EP600YSJM
	CMY-Y200VBK2	For PUHY-P700-P900YSJM
	CMY-Y300VBK2 / 3	For PUHY-P950-P1250 / EP650-EP900YSJM
Branch pipe (Joint)	CMY-Y102SS-G2	200 or below (Total capacity of indoor unit)
	CMY-Y102LS-G2	201-400 (Total capacity of indoor unit)
	CMY-Y202S-G2	401-650 (Total capacity of indoor unit) The 1st branch of P450-P650
	CMY-Y302S-G2	651 or above (Total capacity of indoor unit) The 1st branch of P700-P1250
Branch pipe (Header)	CMY-Y104-G	For 4 branches
	CMY-Y108-G	For 8 branches
	CMY-Y1010-G	For 10 branches
Relay box	PAC-BH02KTY-E	Relay box should be used together with Base heater PAC-BH-EHT-E.
Base heater	PAC-BH01EHT-E	For S Module
	PAC-BH02EHT-E	For L Module
	PAC-BH03EHT-E	For XL Module

Note : Indoor unit capacities: the capacity of an indoor unit is the same as the number used for its type identification.

>>For PUHY-HP series

Description	Model	Remarks
Branch pipe (Joint)	CMY-Y102SS-G2	200 or below (Total capacity of indoor unit)
	CMY-Y102LS-G2	201-400 (Total capacity of indoor unit)
	CMY-Y202S-G2	401-650 (Total capacity of indoor unit) The 1st branch of P400, P500
Branch pipe (Header)	CMY-Y104-G	For 4 branches
	CMY-Y108-G	For 8 branches
	CMY-Y1010-G	For 10 branches
Twinning kit	CMY-Y100VBK2 / 3	For PUHY-HP400, HP500YSHM-A
Relay box	PAC-BH02KTY-E	Relay box should be used together with Base heater PAC-BH-EHT-E.
Base heater	PAC-BH01EHT-E	For S Module

Note : Indoor unit capacities: the capacity of an indoor unit is the same as the number used for its type identification.

>>For PURY series

Description	Model	Remarks
Twinning kit	CMY-R100VBK	For PURY-P400-P650 / EP400-EP600YSJM
	CMY-R200VBK	For PURY-P700-P800YSJM
	CMY-R100XLVBK	For PURY-P800 / EP600-700YSJM
	CMY-R200XLVBK	For PURY-P850-900YSJM
Branch pipe (Joint)	CMY-Y102SS-G2	200 or below (Total capacity of indoor unit)
	CMY-Y102LS-G2	201-400 (Total capacity of indoor unit)
	CMY-Y202S-G2	401-650 (Total capacity of indoor unit) The 1st branch of P450-P650
	CMY-Y302S-G2	651 or above (Total capacity of indoor unit)
Relay box	PAC-BH02KTY-E	Relay box should be used together with Base heater PAC-BH-EHT-E.
Base heater	PAC-BH01EHT-E	For S Module
	PAC-BH02EHT-E	For L Module
	PAC-BH03EHT-E	For XL Module

Note : Indoor unit capacities: the capacity of an indoor unit is the same as the number used for its type identification.

>>For PQHY series

Description	Model	Remarks
Branch pipe (Joint)	CMY-Y102SS-G2	200 or below (Total capacity of indoor unit)
	CMY-Y102LS-G2	201-400 (Total capacity of indoor unit)
	CMY-Y202S-G2	401-650 (Total capacity of indoor unit) The first branch of P400-P600
	CMY-Y302S-G2	651 or above (Total capacity of indoor unit)
Branch pipe (Header)	CMY-Y104-G	For 4 branches
	CMY-Y108-G	For 8 branches
	CMY-Y1010-G	For 10 branches
Twinning kit	CMY-Y100VBK2	For PQHY-P400-P600YSHM-A
	CMY-Y300VBK2	For PQHY-P650-P900YSHM-A

>>For PQR series

Description	Model	Remarks
Branch pipe (Joint)	CMY-Y102SS-G2	200 or below (Total capacity of indoor unit)
	CMY-Y102LS-G2	201-400 (Total capacity of indoor unit)
	CMY-Y202S-G2	401-650 (Total capacity of indoor unit) The first branch of P400-P600
Twinning kit	CMY-Q100VBK	For PQR-P400-P600YSHM-A

OPTIONAL PARTS FOR CONTROL

Model	Description	Model	Description
PAC-SE41TS-E	Remote Sensor for A/J/K/M-Net Control	PAC-YT41HAA	External input/output adaptor for AT-50A
PAC-SE55RA-E	Remote ON/OFF adaptor for Indoor Unit	PAC-YG10HA	External input/output adaptor for AG-150A
PAC-SA88HA-EP	Remote Display Adaptor for Indoor Unit	PAC-YG50ECA	Expansion controller for AG-150A
PAC-SA89TA-EP	Timer Adaptor for remote controller	PAC-SC51KUA	Power supply unit for AG-150A / GB-50ADA-J
PAC-SC37SA-E	Output signal connector	PAC-YG81TB	Mounting attachment B type for AG-150A wall-mount installations
PAC-SC36NA-E	Input signal connector	PAC-YG83UTB	Electric box for AG-150A wall-embed installations
PAC-SF46EPA	Transmission booster	PAC-YG85KTB	Mounting attachment A type for AG-150A/PAC-SC51KUA wall-mount installations
LMA04-E	Air conditioner interface	PAC-YG71CBL	Black surface cover for AG-150A
PAC-YG11CDA	Electric amount count software		
BAC-HD150	BAC net® and M-NET adaptor		

OPTIONAL EQUIPMENT FOR BC CONTROLLER

BC Controller Model	Junction pipe kit	Branch pipe
CMB-P104V-G1, GB1	CMY-R160-J1	CMY-Y102SS-G2
CMB-P105V-G1		
CMB-P106V-G1		
CMB-P108V-G1, GA1, GB1		
CMB-P1010V-G1, GA1		
CMB-P1013V-G1, GA1		
CMB-P1016V-G1, GA1, HA1, HB1		

